



FGB.2057 KIT PCB 960ELT FOR ELEKTRA / ELEKTRA COMPACT..

BOARD ASSEMBLY INSTRUCTIONS




PARAMETER SETTING

To log in parameter menu, press simultaneously **+III** and **+/-** keys for 4 seconds.

The symbol will appear on the display.


Key	Function
-/-	Parameter value decrease
+/-	Parameter value increase
ON/OFF	Exit by parameters menu
+III	Parameter index increase
-III	Parameter index decrease




PARAMETERS

Function	Display	Default	Range
External probe enable (SE)	idx: 001	0	0 - 1
Building dispersion coefficient	idx: 002	35	5 - 35 °C
Sanitary water post-circulation duration	idx: 003	15	1 - 180 sec
Central heating post-circulation duration	idx: 004	30	1 - 180 sec
Primary exchanger ON delay	idx: 005	0	0 - 240 sec
Min. temperature of primary exchanger for circulator ON	idx: 006	30	0 - 50 °C
Sanitary water delivery differential	idx: 007	15	0 - 20 °C
Type of sanitary water storage tank	idx: 008	0	0 = internal with probe 1 = external with thermostat 2 = external with probe
Type of sanitary water request sensor	idx: 009	1	0 = flow switch + three-way pneumatic 1 = flow meter + three-way electric
PWM circulator operation speed	idx: 010	4	1 = 400 l/h 3 = 1.000 l/h 2 = 800 l/h 4 = 1.200 l/h

SELECTION JUMPERS (move jumpers with the board not powered)




Jumper in position 0




Jumper in position 1


Jumper	0	1	Default
JP7	High temperature heating system (radiators)	Low temperature heating system (floor)	0
JP8	Combined application	Central heating only application	0
JP9	Sanitary water system with storage tank	Instantaneous sanitary water system	0
JP10	Boiler application	Screed warmer application	0



GENERAL WIRING DIAGRAM - POWER (Single-phase)



WIRING DIAGRAM (single phase)



Legend of wiring diagrams

Phase	F	Gate command, triac no. 1	G1
Neutral	N	Gate command, triac no. 2	G2
Contactor sectioned phase	FT	Gate command, triac no. 3	G3
Pump	PI	Gate command, triac no. 4	G4
Sanitary water diverter valve control	DHW	Gate command, triac no. 5 (tank)	G5
Central heating diverter valve control	CH	Delivery probe	SM
Diverter valve common	COM	External probe	SE
Sanitary water flow meter	FLM	Sanitary water storage tank probe	SB
Safety earth point on the application	PE	Safety thermostat	TS
Main switch (also disconnects the board)	ON/OFF	Room thermostat	TA
Functional earth derived from the earth point	F.E.	Water pressure switch	PSA
Sanitary water storage tank safety thermostat	TSB		

official distributor for the United Kingdom (GB)



ABCOT UK Ltd.

Green Acres – Oakley Green Road – WINDSOR BERKSHIRE SL4 4QF.

Tel. 01628.636099 - 01628.676900 - Fax. 01628.676958 - E-mail: electricboilerscompany@mail.com

www.electriccombi boilerscompany.com

ELECTRIC
COMBI BOILERS CO.



FIAMMA GIRO s.r.l. Company group



Sede legale e stabilimento: via L. Landucci n°.2/B - 51100 PISTOIA - ITALY

Tel.(+39).0573.532812 Fax.(+39).0573.532890 - E.mail: fiammaPT@fiammagiro.it

Filiale e stabilimento: via P. Bettini n°.19 - 37049 VILLA BARTOLOMEA (VR) - ITALY

Tel.(+39).0442.659028 Fax.(+39).0442.659045 - E-mail: fiammaVR@fiammagiro.it

www.fiammagiro.com