



TOOLS YOU WILL NEED

- Drill and drill bits
- Fine toothed saw / jigsaw
- Small spirit level
- Screwdriver
- Adhesive (No Nails / Mitre Glue)
- Silicone gun

0:10

SAFETY FIRST

- ⚠ Use RCD or battery tools near water.
- ⚠ Wear eye protection when drilling.
- ⚠ Check for hidden pipes or cables before drilling.

0:18

IMPORTANT DISCLAIMER

All baths are different. These instructions are provided as a general guide only to help with the installation of Aquacloak Flexible Bath Panels.

In some cases, due to the design of the bath, room conditions or other factors, you may encounter issues not covered in this guide.

The installer is responsible for assessing each situation and using alternative methods where necessary to achieve a safe and secure fit.

0:28

1 PLAN & TEMPLATE

Use a card template and draw around the "P/B or Offset" area (Fig 1). Cut the template 20mm inside the line.

0:40

2 PREPARE CURVED FRAMES

Use the template to mark the curve on the wood. Cut two curved frames approx. 25mm wide – one for the top and one for the floor (Fig 1.2).

1:00

3 FIX TOP CURVED FRAME

Fix the top curved frame with adhesive (No Nails / Mitre Glue) at least 20mm in from the bath lip. Use small clamps to hold while the adhesive sets (Fig 2).

1:18

4 MIRROR TO FLOOR

When set, use a spirit level to mirror the curve to the floor at both ends (Fig 2). Fix the bottom curved frame with adhesive. Allow to cure.

1:35

5 ADD STRAIGHT BATTENS

Add straight 25mm battens along the straight sections (top and bottom), at least 20mm in from the bath lip.

Note: Use existing bath support blocks or add extra softwood blocks if needed.

1:52

7 FIX BLOCKS BEHIND SLATS

Fix a block behind each slat at top and bottom, flush to the rear of the slat, using No Nails / Mitre Glue to the batten. DO NOT fix to the slats yet. Repeat for all slats.

8 REMOVE SLATS

Once adhesive on blocks has cured, remove all slats, keeping them in the same order as removed. (If using gloss slats, remove protective film now.)

9 GLUE SLATS IN PLACE

Starting from the wall end (or corner), glue slats into position with No Nails / Mitre Glue. Use card wedges to hold until adhesive cures.

10 ACCESS OPENING (OPTIONAL)

For access to taps or wastes, use optional Clips or Velcro on the blocks. Make the access opening by using the whole of two adjacent slats (available separately).

11 FINAL CHECK

Once adhesive has cured, remove card wedges. Check each slat is secure and aligned.

12 SEAL EDGES

Seal the top edge, sides and bottom where the panel meets the wall and floor with a sanitary silicone sealant (Fig 8).

