



## **DEBUS WING CANOPY USER GUIDE**



### **SCOPE**

This user guide applies to the Debus WING Canopy – Midnight Black (DEB25006BLK) only.

**Designed to fit vehicles with a connection height of up to 210cm only**

### **CONTENTS**

- 1 x WING canopy
- 2 x height adjustable aluminium poles
- 8 x adjustable webbing straps
- 8 x steel rock pegs with luminous heads
- 1 x material repair kit
- 1 x Carry bag with handles

### **BEFORE USE**

Select a level, flat surface. Clear away any sharp objects that could damage the fabric.

### **CONNECTION METHODS**

3 methods can be used to connect the Debus WING Canopy:

- 1). Twin 4/6mm kador beading connects to awning rails and wind out awnings
- 2). Pole sleeve to be used with a pole and clamp kit (not included) to connect via a roof gutter
- 3). Throw-over straps which are a universal connection for vehicles without an awning rail

## QUICK SET UP GUIDE

### AWNING RAIL CONNECTION

- Remove the canopy from the carry bag and place flat on the ground with the beading facing the vehicle.
- Slide either the 4 or 6mm beading into your awning rail channel.
- Insert an aluminium pole through a corner eyelet and extend the pole to the approximate height of the vehicle. Buckle in a webbing strap to the female clip at the corner eyelet. Adjust the webbing strap to provide strong tension and peg down at a 45 degree angle from the corner pole.
- Insert the second aluminium pole through the opposite corner eyelet and extend the pole to the same height as the first pole. Buckle in a webbing strap to the female clip at the corner eyelet. Adjust the webbing strap to provide strong tension and peg down at a 45 degree angle from the corner pole.
- The canopy should now be able to support itself.
- Peg down the shorter webbing straps at the base of both side walls.
- Both side walls can be rolled up and secured with sewn in toggles to create a fully open canopy as shown in FIG 1 below.
- Additional aluminium poles and guy lines (not included) can be purchased to extend out one or both sides as shown in FIG 2 below.

FIG 1



FIG 2



### POLE & CLAMP KIT CONNECTION

- Slide the pole through the canopy pole sleeve and position in the roof gutter rail.
- Secure the pole at each end with the pole clamps, angling the clamps upwards so they do not obstruct the van doors.
- Follow the same pitching process as above.

## **THROW OVER STRAPS CONNECTION**

- Buckle in the throw over webbing straps to the female clips on the connection edge of the canopy.
- Extend the length of the straps and throw them over the top of the vehicle.
- Peg each strap down securely slightly wider than the connection edge to improve tension.
- Adjust the straps until the connection edge of the canopy is sitting tightly onto the roof of the vehicle.
- Follow the same pitching process as above.

## **CARE FOR INSTRUCTIONS**

Let the canopy dry completely before placing it back in the bag provided  
Clean off any dirt using a sponge and warm water.  
Do not use detergent.  
Keep away from sparks, flames, and other ignition sources.

## **SPECIFICATION**

Connection height range: Up to 210cm  
Kador connection length: 240cm  
Canopy dimensions: W x 250cm D x 210cm Adjustable height 80 – 220cm  
Material: DebeX Fabric (150D Oxford polyester, 3000mm HH, SPF 50+)  
Weight: 3.5kg

## **WARRANTY**

This product carries a 1 year manufacturing defect warranty as standard. Increase your warranty by an extra 1 year by registering the product within 1 month from the date of purchase. Scan the QR code below to complete the warranty form on the Debus website:



E-Mail: [contact@debus.co.uk](mailto:contact@debus.co.uk) Website: [www.debus.uk](http://www.debus.uk)

Made in China on behalf of Debus Designs Ltd, The Barn, Brookwood Farm, Fenny Bentley, Ashbourne, Derbyshire, UK, DE6 1LE

*Version 1 March 2026*