

Elite Evo Floor Stand & Accessories

Getting Started Guide

Follow this guide to set up your Elite Evo Floor Stand Accessories.

Contents

Firstly, set up your Evo Floor Stand and Holder.
Then follow the relevant instructions
for your accessory(ies).

Evo Floor Stand & Elite Holder


Evo Floor Stand	2
Elite Holder	4

Accessories

Brother Printer Bracket	6
Payment Device Bracket	8
Sign Holder Bracket	10
Optional Extras	12

Evo Floor Stand

First, let's set up your Evo Floor Stand.
Locate the below items and continue to Step 1.



Hinge Pole



Base Pole



Baseplate




x3 Baseplate
Screws



x2 Grub
Screws



x1 Allen Key



Step 1 Feed tablet charging cable down through the Hinge Pole. Ensure enough length is fed through to easily plug into your tablet.




Step 2 If you need to run an additional cable to power your accessory(ies), remove x3 screws from the Connector on the Base Pole, and slide out the Connector.



Step 3 Feed accessory cable(s) up through the Base Pole, then up the Hinge Pole, and finally out through the cable cutout.



Step 4 Reattach the connector and screw back in x3 screws. Feed the tablet charging cable down through the Base Pole.



Step 5 Slide the Hinge Pole onto the Base Pole. Screw in Crub Screws with Allen Key to secure.



Step 6 Run the charging cable(s) through the Baseplate, then screw on the Baseplate Screws from underneath.

Elite Holder

Locate the below items along with your tablet device and charging cable and continue to Step 1.




Elite Holder




Keys



x4 Screws




Step 1 Locate the Elite Holder and attach to the hinge and screw in the x4 screws to secure.



Step 2 Unlock the Elite Holder with keys provided and, if applicable, slide the latch to remove the faceplate.




Step 3 Remove the faceplate.



Step 4 Plug in your tablet while placing it into the holder.



Step 5 Hook faceplate back on the case.



Step 6 Lock the faceplate with Keys provided before use.

Brother Printer Bracket

Locate the below items along with your
Brother Printer QL-820 and continue to Step 1.



Brother Printer
Bracket



x2 Clamps



x1 Allen Key




x4 Socket
Head Screws




x4 Countersunk
Screws




x4 Pan Head
Screws




Step 1 Insert Socket Head Screws into the bottom 2 holes of each clamp to attach them to the pole. Leave loose for adjustments.



Step 2 Use Countersunk Screws in the top 2 holes of each Clamp to attach the Brother Printer Bracket to the Evo Pole.



Step 3 Partially insert the x2 Pan Head Screws into the Brother Printer QL-820, leaving a gap between the Printer and the screw head. Hook these in using the Keyhole Slot on the Brother Printer Bracket.



Step 4 Attach the Brother Printer QL-820 to the Bracket by aligning the screws with the Keyhole Slot and placing it in position. Then tighten the x2 Pan Head Screws to secure it and plug in the charging cable.

Payment Device Bracket

Locate the below items along with your payment device and continue to Step 1.



Payment Device
Bracket



Clamp



x1 Allen Key




x4 Socket
Head Screws




x4 Pan Head
Screws




Adhesive




Step 1 Attach the Clamp to the pole using x4 Socket Head Screws.



Step 2 Attach the Payment Device Bracket to the stand using x4 Pan Head Screws.



Step 3 If required, cut supplied Adhesive to required size.



Step 4 Attach your payment device to the bracket using the Adhesive and plug in charging cable.

Sign Holder Bracket

Locate the below items along with your sign and continue to Step 1.



Sign Holder Bracket



Clamp



x1 Allen Key



x4 Socket Head Screws




x4 Pan Head Screws




x4 Nuts




x4 Philips Head Screws



Step 1 Attach the Clamp to the pole using x4 Socket Head Screws.




Step 2 Attach the Sign Holder Bracket to the stand using x4 Pan Head Screws.



Step 3 Attach your sign to the Bracket using x4 Phillips Head Screws and x4 Nuts.


Optional Extras

Follow these steps to install the cable cutout, tilt adjustment or rotation lock (for Evo X only).




Cable Cutout Unscrew existing closed cable cutout and install the open cable cutout included with stand.

Evo X Only



Rotation Lock To lock rotation, remove holder and screw lock screw as shown to lock. Then attach the holder in desired position.

Evo X Only



Tilt Adjustment Lock Using Allen Key provided, tighten screw at desired angle to lock in position.



US Customer Support

1800 293 9703

sales@bosstab.com

Australia Customer Support

1800 870 132

sales@bosstab.com.au

Warranty & Returns

If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit & we'll pay for the return postage costs.

We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy & initiate a return please visit www.bosstab.com