

# Elite Flex Arm


## Getting Started Guide

Follow this guide to set up your Elite Flex Arm.

# Parts List

---

Locate the below items along with your tablet device and charging cable and continue to Step 1.



Elite Holder



Flex Arm  
Stand




Keys




x4 Wood  
Screws

## Step-by-Step Instructions

---




**Step 1** Place the flex arm on your counter and drill pilot holes.




**Step 2** If you are running your charging cable through the surface, ensure to drill a larger hole to feed cable through.

## Step-by-Step Instructions

---




**Step 3** Screw down your Flex Arm pole using wood screws provided and then cover holes with rubber plugs.



**Step 4** Place Elite holder on Flex Arm pole & screw in the 4 screws.



**Step 5** Unlock case with keys provided & remove faceplate. Unlock the Elite Holder with keys provided and, if applicable, slide the latch to remove the faceplate.



**Step 6** Plug in charging cable & place tablet into case, place faceplate back on & lock.



US Customer Support

**1800 293 9703**

sales@bosstab.com

Australia Customer Support

**1800 870 132**

sales@bosstab.com.au

### **Warranty & Returns**

If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit & we'll pay for the return postage costs.

We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy & initiate a return please visit [www.bosstab.com](http://www.bosstab.com)