

Elite


With Nexus Pole

Getting Started Guide

Follow this guide to set up your Elite
Nexus as a wall mounted tablet stand.

Wall Mounting

Locate the below items along with your tablet and charging cable to begin.



Elite holder



Nexus base



Elite key



x4 M4
Screws




x2 Wood
Screws




Step 1 Locate the Nexus base and follow the above locations to line up your surface mounting & cable feed.


Step 2 Drill pilot holes to assist with screw base mounting. Refer to the mounting guide for assistance.




Step 3 If you are running your charging cable through the surface, ensure to drill a larger hole to feed cable through.



Step 4 With the cable channel facing out the left hand side of the stand, screw down your stand using the wood screws provided.



Step 5 Locate your Elite Holder and place it on the stand, securing it with x4 screws. Unlock the Elite Holder with keys provided and, if applicable, slide the latch to remove the faceplate.



Step 6 Place your tablet in the holder & plug in charging cable then put the faceplate on & lock.

Extras


Follow these steps to install the position lock to disable 180° swivel movement. Locate the below Allen key to install.




Allen Key



Bolt



Nexus Stand Position Lock Rotate stand 45 degrees so cable hole is on the left, then screw in lock screw as shown. This will lock the rotation for a fixed option.



Elite Cable Cutout Unscrew existing closed cable cutout & install the open cable cutout included with stand.



US Customer Support

1800 293 9703

sales@bosstab.com

Australia Customer Support

1800 870 132

sales@bosstab.com.au

Warranty & Returns If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit & we'll pay for the return postage costs. We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy & initiate a return please visit www.bosstab.com