

# Touch

With Evo Stand

## Getting Started Guide


Follow this guide to set up your Touch Evo as a screw mounted or freestanding tablet stand.

# Touch

Follow these steps to attach your tablet to the Touch holder. Locate the below items along with your tablet device and charging cable and continue to Step 1.



Touch holder




Evo / Evo X  
Stand




Security key




x4 Screws




**Step 1** Locate the Touch holder and unscrew the security screw to remove the top bracket that holds the adhesive.



**Step 2** Attach the Touch holder to the stand and screw in the x4 screws to secure.



**Step 3** Peel off the adhesive paper from the top bracket.



**Step 4** Place the bracket in the center of the tablet and press down and hold for 20 seconds.

# Screw Mounting

Firstly, ensure you have followed the steps on page 2 to attach your tablet to the Touch holder before continuing.


Follow these steps for desktop & wall mounting. Locate the below items along with your tablet (with Touch holder attached) & charging cable.




Security key




x3 Wood  
Screws




**Step 1** Lift the Evo pole base cover from the base plate & drill pilot holes.



**Step 2** If you are running your charging cable through the surface, ensure to drill a larger hole to feed cable through.



**Step 3** Screw down your Evo pole through the base plate using the wood screws provided & then press down base cover.



**Step 4** Finally, attach the top bracket (with tablet attached) and screw in the screw using the security key and plug in charging cable.


# Freestanding

Firstly, ensure you have followed the steps on page 2 to attach your tablet to the Touch holder before continuing.


Locate the below items along with your tablet (with Touch holder attached) & charging cable.



Security key



**Step 1** Attach the top bracket (with your tablet attached) to the stand. Ensure charging cable runs through the cable channel.




**Step 2** Finally, screw in the security screw with the provided security key and plug in charging cable.

# Extras


Follow these steps to install the cable cutout  
(for Elite holder only) or tilt adjustment and  
rotation lock (for Evo X only).

Evo X Only



**Tilt Adjustment Lock** Using Allen key provided, tighten screw at desired angle to lock in position.

Evo X Only



**Rotation Lock** To lock rotation, remove holder and screw lock screw as shown to lock. Then attach the holder in desired position.



US Customer Support

**1800 293 9703**

[sales@bosstab.com](mailto:sales@bosstab.com)

Australia Customer Support

**1800 870 132**

[sales@bosstab.com.au](mailto:sales@bosstab.com.au)

**Warranty & Returns** If you receive an item that is faulty or damaged then you can send it back for a refund, replacement or store credit & we'll pay for the return postage costs. We offer a 12 month warranty on items that are deemed defective by the manufacturer. If you have a defective product covered by this warranty, we will either repair using new or refurbished parts, or if repair is not possible, replace the item. The warranty will not cover loss or theft, nor damage deemed to be caused by misuse or unauthorized modification. To view our full returns policy & initiate a return please visit [www.bosstab.com](http://www.bosstab.com)