



## KB 5

The Kärcher cordless sweeper picks up dirt, debris, pet hair and crumbs in seconds, then stores away neatly until you next need it. It's simple to use and easy to empty.



### 1 Kärcher Adaptive Cleaning System

- Reliably removes dirt on all floor surfaces.
- Innovative adjustable sweeping edge for optimal dirt pick-up.

### 2 Dirt receptacle is easy to remove and refit again

- Quick and easy emptying without coming into contact with dirt.

### 3 Flexible double joint

- The handle can be moved effortlessly in all directions.
- Easy to manoeuvre.

### 4 Automatic on/off switch

- Easy to switch on and off.
- Fast and intuitive.



## KB 5

- Dirt receptacle is easy to remove and refit again
- Kärcher Adaptive Cleaning System
- Flexible double joint for easy manoeuvring

### Technical data

<b>Order Number</b>	1.258-001.0	
<b>EAN code</b>	4054278238685	
<b>Container capacity</b>	ml	370
<b>Battery voltage</b>	V	3,7
<b>Battery running time on hard floors</b>	min.	30
<b>Battery running time on carpets</b>	min.	20
<b>Battery technology</b>	lithium-ion battery (Li-Ion)	
<b>Weight including battery</b>	kg	1,17
<b>Dimensions (L x W x H)</b>	mm	215 × 230 × 1120
<b>Current type</b>	V / Hz	100-240 / 50-60
	mm	210

### Equipment

<b>Universal brush</b>	removable
<b>Battery charger</b>	■

■ Included in delivery.