

TOP POST SECTION


BACKBAR SECTION

E | CROSSBAR SECTION


G SIDEBAR SECTION


H UPRIGHT SECTION

ANCHOR YOUR GOAL POSTS During a game the posts must have the ground anchors inserted as shown below, in order to fully hold the goal post ground sections together. NOTE: All plastic extrusions vary




· D E H ·H






WORLDWIDE © COPYRIGHT 2001 ITSA GOAL, ALL RIGHTS RESERVED A REGISTERED DESIGN

WE RESERVE THE RIGHTS TO AMEND THE SPECIFICATIONS OF OUR PRODUCTS IN THE INTEREST OF CONTINUED DEVELOPMENT. YOUR PRODUCT THEREFORE MAY DIFFER LIGHTLY TO THOSE ILLUSTRATED. E&OE







SPARE PARTS & EXTENSIONS

AVAILABLE TEL 0114 2424244

