

1 Mirror your image or artwork

2 Cut your image using a contour/plotter cutter or for more simple designs you can use scissors

CRICUT GUIDELINES*
 SETTING **Standard Iron On**
 BLADE **Standard**
 PRESSURE **Default**

SILHOUETTE BLADE SETTING* **3**
 SPEED **8** FORCE **6**

*Adjust as necessary. Use a cutting mat (carrier sheet) and cut through the film layer only. Test cuts are recommended.

3 Weed away excessive material (a weeding tool may help)

4 Prepare the heat press at **150°C / 305°F**.
 If using an iron, set dial between Cotton and Linen

5 Place image face down on substrate.
 If using an iron, place on flat, hard surface (ironing board not recommended)

6 Cover with a Teflon or silicone sheet

7 Apply **medium** pressure for **15 seconds**.
 If using iron, press with medium/firm pressure (do not slide iron). Press each section of design for 10-15 seconds.

8

Hot or Cold Peel*

24hrs before washing

*If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds

wash and care instructions



Machine wash separately



Dry on cotton cycle



Do not bleach, dry clean or directly iron image

contact

hello@yolo.co.uk

+44 (0) 2082 400 658

www.yolo.co.uk

Product code: **EZW**

Store in a cool, dry place and seal the packaging between uses