DEBUS 5PLY CAMPERVAN COVER USER GUIDE



SCOPE

This user guide applies to the below Debus 5ply Campervan Covers only:

DEB26001 Debus 5ply Campervan Cover – Suitable for Volkswagen T2 Bay Window & Split Screen campervans

DEB26002 Debus 5ply Campervan Cover - Suitable for Volkswagen T25, T3, T4, T5, T6, T7 ID. Buzz and Ford Transit Custom vans.

DEB26003 Debus 5ply Campervan Cover - Suitable for Volkswagen Crafters, Mercedes Sprinter; Fiat Ducato & Peugeot Boxer vans

All 3 covers are compatible with Short Wheelbase (SWB) & Long Wheelbase (LWB) vehicles. Standard & High-Top Roofs. Rear Bike Racks or Ladders. Side Wind-Out Awnings

CONTENTS

DEB26001 VW T2: 2 x side straps, 3 x rear straps, 1 x material repair kit, carry bag

DEB26002 VW T5/T6: 3 x side straps, 3 x rear straps, 1 x material repair kit, carry bag

DEB26003 VW Crafter: 4 x side straps, 3 x rear straps, 1 x material repair kit, carry bag

BEFORE USE

- Remove, fold away, or protect any sharp or fragile exterior fitting on the campervan (ie aerials & solar panels) to prevent damage to the cover.
- Close all windows and make sure the roof is fully closed.
- Switch off appliances such as fridges and heaters, apply the handbrake.
- Ensure the campervan is dry before fitting the cover. It must be clean and free from loose dirt, grit, or debris to prevent scratching.

FITTING GUIDE

- It is recommended that two people fit the cover safely.
- Use stepladders or a stable platform only when necessary to assist those working from the ground. Do not attempt to fit the cover while standing on a ladder.
- When working at height, always follow the ladder or platform manufacturer's safety instructions.
- Fully unfold the cover and locate the section marked with the "FRONT" label.
- Fully open both zips.
- Starting at the front and working towards the rear, carefully lift the cover over the roof and any protruding fittings. To aid this process, awning or canopy king poles can be placed under each corner of the cover to help guide it over the vehicle from ground level.
- Adjust the cover until it fits evenly over the entire van.
- Carefully close the zips and secure the hook-and-loop tabs at the bottom.
- Pass each side strap underneath the van and connect it to the corresponding buckle on the opposite side.
- Adjust the side and rear straps until the cover fits securely, taking care not to overtighten them.

GUIDANCE

- Do not fit the cover during windy conditions.
- Never use the campervan's heating system while the cover is fitted.
- Do not drive or move the campervan with the cover in place.
- Before opening or closing a zip, ensure the surrounding cover is straight and not pulled too tightly. This reduces strain and helps prevent zip failure.
- Do not overtighten the straps, as this may damage the cover.
- During long-term storage, ventilate the vehicle regularly and consider using a dehumidifier to help prevent mould growth inside.
- Clean the vehicle's exterior regularly during long-term storage to reduce the risk of mould developing between the bodywork and the cover.

CARE FOR INSTRUCTIONS

Let the cover dry completely before placing it back in the bag provided
Clean off any dirt using a sponge and warm water.
Do not use detergent.
Keep away from sparks, flames, and other ignition sources

SPECIFCATION

Material: 5-Ply Non-Woven Polypropylene, UPF 50+, 1000mm HH

Colour: Dark Grey

DEB26001 VW T2 dimensions: L x 5m, W x 2m, H x 1.7m

DEB26002 VW T5/T6 dimensions: L x 5m, W x 2m, H x 1.7m

DEB26003 VW Crafter dimensions: L x 5.9m, W x 2m, H x 2.4m

WARRANTY

The product carries a 1 year manufacturing defect warranty as standard. Increase your warranty by an extra 1 year by registering the product within 1 month from the date of purchase. Scan the QR code below to complete the warranty form on the Debus website:

E-Mail: contact@debus.co.uk Website: www.debus.uk

Made in China on behalf of Debus Designs Ltd, The Barn, Brookwood Farm, Fenny Bentley, Ashbourne, Derbyshire, UK, DE6 1LE

Version 1 August 2026