



CL TRIMFREE

APPLICATION TIPS









Pre-Press Shirt

To remove moisture and bring the shirt to the correct pressing temperature it is critical that the shirt is pre-pressed prior to applying the transfer.

Pressure

TrimFree, as with all transfer papers for light shirts, requires Maximum pressure. Using maximum pressure will ensure the transfer paper will peel correctly and increase the washability of the design.

Peeling

It is important to wait 7 to 10 seconds prior to peeling the transfer. Do not remove the shirt from the press prior to peeling, doing so will cause the transfer to cool too quickly making the transfer difficult to peel.

When peeling, use a slow and consistent motion.

DO NOT cover your transfer with Teflon when pressing TrimFree.

Fabric Types – 7 to 10 Second Wait Time

TrimFree will work well on cotton, cotton blends and polyester. Most t-shirt fabrics only require a 7 second wait period prior to peeling, heavier fabrics such as sweat shirt material usually require the full 10 seconds. Because there is such a wide variety to different fabrics we suggest you test your material to determine the best wait time.

Paper Mode

For the fuser to properly fuse the toner to the paper we suggest using Heavy Paper or Label Mode. You may need to test 2 or 3 different settings to find the best setting for your printer. To check for good toner adhesion, run your finger across the printed image. If any toner transfers to your finger you should set your paper mode setting on your print driver to a heavier setting.

Loading and Exit Tray

TrimFree should be printed using the by-pass tray. If your printer has a rear exit door that will allow the paper to exit straight out the back we suggest you test the paper using this configuration.

Suitable Graphics

TrimFree works best with graphics and designs that have solid colors such as corporate logos or plain type.

TrimFree is best suited for logos or graphics, if you are printing large square images or photographs we suggest using Paropy CL 135.

Printers/Copiers Tested

OKI DATA	Recommended
CANON	Reommended
XEROX	Recommended
SAMSUNG	Recommended
RICOH	Recommended
HP	Not Recommended
BROTHER	Not Recommenddd

Although testing has been done on the above brands of printers, it is recommended that you do your own testing due to the many different models in the market.

www.merlintransfers.com





CL TRIMFREE

APPLICATION INSTRUCTIONS

STEP BY STEP

Step 1

Feed material into laser printer so that the printer is printing on the printable side (white matte coated side).

Step 2

Design your image and and resize if necessary

Step 3

Prepress fabric for 5-10 seconds.

Step 4

Place imaged CL TrimFree on fabric with image face down.

Step 5

Heat apply the transfer onto the shirt. Press at 330-340F at 25-30 seconds. Use maximum pressure

Step 6

Do not remove fabric

from heat press. Peel transfer off warm. Wait approximately 7-10 seconds before peeling

Step 7

Repress imaged t-shirt for 30 seconds at 330F using enclosed silicon sheet. This will seal the coating to allow better wash resistance.

APPLICATION

Printer: Laser Non-Oil

Recommended Paper Mode Heavy or Label mode

Image: Mirror
Press Time: 25-30 sec.

Temperature: 330-340F (165-170C)

Pressure: Maximum

Peel: Warm (wait 7-10 seconds)

Wash Temp.: Up to 105F (40C)

All technical information and recommendations are based on tests we have conducted.

Users should conduct their own tests before proceeding

Notes

Recommended Fabrics

White or Light colored: 100% cotton 100% polyester Poly/cotton blends Polyester knits Polyester mesh Poly/foam & cotton caps Satin

Accessories Required

Computer, Color Laser Printer, Heat Press.

Printable side

The printable side is the white matte coated side.

Pressure Settings

To ensure that the coating has properly fused with the fabric, we recommend to use maximum pressure. If this paper is applied with inadequate pressure, the transfer will not wash well.

Peeling

This paper is to be peeled warm. Peeling should occur 7-10 seconds after pressing. Also if you have difficulties peeling the backing off the shirt, while the fabric is hot, gently tug on the sides of the shirt, the backing will "pop" right out. Depending on fabric and toner coverage, wait time before peeling will vary. Test before commerical production.

Care Instructions

Wait 24 hours before washing.
Machine wash using mild detergent.
Do not use bleach or other aggressive cleaning agents. Cannot be dry cleaned. Wash Temperature cannot exceed 105F

Storage

CL TrimFree has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity.

www.merlintransfers.com





CL TRIMFREE PLUS FOIL

Application Instructions (1 of 2)

STEP BY STEP

Step 1

Feed material into laser printer so that the printer is printing on the printable side (white matte coated side).

Step 2

It is recommended to use black only when doing foil. Design your black only image and and resize if necessary

Step 3

Prepress fabric for 5-10 seconds.

Step 4

Place imaged CL TrimFree on fabric with image face down.

Step 5

Heat apply the transfer onto the shirt. Press at 330-340F at 25-30 seconds. Use maximum pressure

Step 6

from heat press. Peel transfer off warm. Wait approximately 7-10 seconds before peeling

Do not remove fabric

APPLICATION

Printer: Laser Non-Oil

Recommended Paper Mode Heavy or Label mode

Image: Mirror
Press Time: 25-30 sec.

Temperature: 330-340F (165-170C)

Pressure: Maximum

Peel: Warm (wait 7-10 seconds)

Wash Temp.: Up to 105F (40C)

All technical information and recommendations are based on tests we have conducted.

Users should conduct their own tests before proceeding

Notes

Recommended Fabrics

White, Light, or Dark colored:

100% cotton 100% polyester Poly/cotton blends Polyester knits Polyester mesh Poly/foam & cotton caps Satin

Accessories Required

Computer, Color Laser Printer, Heat Press.

Printable side

The printable side is the white matte coated side.

Pressure Settings

To ensure that the coating has properly fused with the fabric, we recommend to use maximum pressure. If this paper is applied with inadequate pressure, the transfer will not wash well.

Peeling

This paper is to be peeled warm. Peeling should occur 7-10 seconds after pressing. Also if you have difficulties peeling the backing off the shirt, while the fabric is hot, gently tug on the sides of the shirt, the backing will "pop" right out. Depending on fabric and toner coverage, wait time before peeling will vary. Test before commerical production.

Care Instructions

Wait 24 hours before washing.
Machine wash using mild detergent.
Do not use bleach or other aggressive cleaning agents. Cannot be dry cleaned. Wash Temperature cannot exceed 105F

Storage

CL TrimFree has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity.

ADDITIONAL APPLICATION INSTRUCTIONS, SEE OTHER SIDE

www.merlintransfers.com

Any enquiries relating to our products and their usage are always welcome. If you find yourself unsure of how to use this product, please feel free to contact us on Tel: 01702 600200 email: sales@merlintransfers.com





CL TRIMFREE PLUS FOIL

Application Instructions (2 of 2)

STEP BY STEP

Step 7

Once you have pressed your TrimFree image onto fabric, place foil on top of the transfer with colored side face up

Step 8

Press at 330-340F at 25-30 seconds. Use maximum pressure

Step 9

Carefully peel the foil off cold using a consistent and smooth motion.

Step 10

Repress imaged t-shirt for 30 seconds at 330F using enclosed silicon sheet. This will seal the foil to allow better wash resistance.

APPLICATION

Application:

Fabric Color: White, Light, or Dark colored Fabrics

Recommended image: All Black

Press Time: 25-30 sec.

Temperature: 330-340F (165-170C)

Pressure: Maximum
Peel: Cold

Wash Temp.: Up to 105F (40C)

All technical information and recommendations are based on tests we have conducted.

Users should conduct their own tests before proceeding

Foil

Notes

Recommended Fabrics

White, Light, or Dark colored:

100% cotton 100% polyester Poly/cotton blends Polyester knits Polyester mesh Poly/foam & cotton caps Satin

Accessories Required

Computer, Color Laser Printer, Heat Press. Imaged CL TrimFree fabric, Foil

Pressure Settings

To ensure that the foil has properly fused with the fabric, we recommend to use maximum pressure. If this paper is applied with inadequate pressure, the foil may not stick to fabric

Recommened image

It is recommened to use a full black image. This will ensure consistent foil color and that the foil is applied evenly across the whole image

Recommened image

In addition, having an all black image will allow you to be able to see where the foil will be applied before pressing.

Peeling

The foil is to be peeled cold. If it is peeled warm or hot, some of the gold foil may not stick entirely onto the imaged CL TrimFree Transfer.

Care Instructions

Wait 24 hours before washing. Machine wash using mild detergent. Do not use bleach or other aggressive cleaning agents. Cannot be dry cleaned. Wash Temperature cannot exceed 105F

Storage

CL TrimFree Foil has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity. Be careful not to unroll the foil before using as it may be difficult to reroll.

www.merlintransfers.com